

Engine Block Tools

Universal Cam Bearing Installation Kit

- Best available to cleanly and accurately install or remove cam bearings from any engine block
- With a range of 1.125" to 2.690", this tool should handle any size or make of engine you might encounter
- Kit's five expanding mandrels are neoprene covered to protect the inner surface of the bearings and prevent grooving
- A centering cone, extension rod & case are included

Lose a part? We readily offer replacement components for our entire Cam Bearing Kit.



POW101025

POW101025	Universal Cam Bearing Installation Kit	Buy Now!
Replacement Parts		
POW180200	Cam Bearing Collet Set – 1.475"-1.700"	Buy Now!
POW180400	Cam Bearing Collet Set – 1.700"-1.925"	Buy Now!
POW180600	Cam Bearing Collet Set – 1.925"-2.150"	Buy Now!
POW180800	Cam Bearing Collet Set – 2.150"-2.375"	Buy Now!
POW181000	Cam Bearing Collet Set – 2.375"-2.690"	Buy Now!
POW184100	Rubber Sleeve – 1.125"-1.475"	Buy Now!
POW181200	Rubber Sleeve – 1.475"-1.700"	Buy Now!
POW181400	Rubber Sleeve – 1.700"-1.925"	Buy Now!
POW181600	Rubber Sleeve – 1.925"-2.150"	Buy Now!
POW181800	Rubber Sleeve – 2.150"-2.375"	Buy Now!
POW182000	Rubber Sleeve – 2.375"-2.690"	Buy Now!
POW182200	Driver Bar	Buy Now!
POW182300	Driver Extension	Buy Now!
POW182500	Driver Stud	Buy Now!
POW182800	Expander Cone	Buy Now!
POW183300	Expander Assembly	Buy Now!
POW183400	Expander Shaft & Cone	Buy Now!
POW183500	Expander Segment Set	Buy Now!
POW183900	Nylon Cone	Buy Now!
POW184300	Small Washer – 1.125"-1.700"	Buy Now!
POW184200	Large Washer – 1.700"-2.690"	Buy Now!

POW180200



POW183400



POW183500



Oil Pump Primers

- Allow oil pump to be primed & engine prelubed prior to install start-up
- Eliminate chance of "dry start" & premature engine damage
- Chevy tool also includes bushing to pressurize the upper valve train
- Pro-model (Part# POW101150) has a top alignment collar

POW101150	Oil Pump Primer – All Chevy V8 & 90° V6 (w/ Bushing)	Buy Now!
POW101155	Oil Pump Primer – Ford 260-351W (1/4" Hex Drive)	Buy Now!
POW101160	Oil Pump Primer – Ford 302-351C&M & 400-460 (5/16" Hex Drive)	Buy Now!

POW101150

